# GLOBAL PROCUREMENT AND MARKETING LIMITED

## TV Unit 1300

| Assembly Instructions - Please keep for future reference | TVSAVOGRY | |
|---|---|---|
| | | |




| Dimensions | No. people | Assembly Time | SKU # |
|---|---|---|---|
| Width: 130cm<br>Depth: 39cm<br>Height: 50cm | | 45 mins<br>(approx.) | TVSAVOGRY |

*thank you*

For purchasing this **GPM Limited** product

**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please email **aftersales@gpmfurniture.co.uk**

# Safety and Care Advice

**Important** - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 4 and 5.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft, level surface to avoid damaging the unit or your floor.
- We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.

- Dispose of all packaging carefully and responsibly.

## Care and Maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

**If you are unhappy with the product and wish to return it, please follow the retailer's returns procedure.**

# Exploded View

If you have damaged or missing components,
email: **aftersales@gpmfurniture.co.uk**



# Components - Fixings

If you have damaged or missing components,
email: **aftersales@gpmfurniture.co.uk**

**Please check that you have all the components listed below before constructing your item.**

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| **(A)** | 12pcs | **(B)** |  12pcs | **(C)** | 20pcs | **(D)** | 5pcs |
| **(E)** | 4pcs | **(F)** | 10pcs | **(G)** |  2pcs | **(H)** | 2pcs |
| **(I)** | 2pcs | **(J)** | 10pcs | **(K)** | 4pcs | **(L)** | 2pcs |
| **(M)** | 2pcs | **(N)** | 4pcs | **(O)** | 8pcs | **(P)** |  1pc |
| **(Q)** | 4pcs | | | | | | |
| | | | | | | | |

**Tools Required**



**Ruler -** Use this to measure your screws (mm)




**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please email **aftersales@gpmfurniture.co.uk**

# Assembly Instructions

If you have damaged or missing components,
email: **aftersales@gpmfurniture.co.uk**

## Step 1




## Step 2



# Assembly Instructions

If you have damaged or missing components,
email: **aftersales@gpmfurniture.co.uk**

## Step 3




## Step 4



# Assembly Instructions

If you have damaged or missing components,
email: **aftersales@gpmfurniture.co.uk**

## Step 5




## Step 6



# Assembly Instructions

If you have damaged or missing components,
email: **aftersales@gpmfurniture.co.uk**

## Step 7




## Step 8



# Assembly Instructions

If you have damaged or missing components,
email: **aftersales@gpmfurniture.co.uk**

## Step 9




## Step 10



# Assembly Instructions

If you have damaged or missing components,
email: **aftersales@gpmfurniture.co.uk**

## Step 11




x2

## Step 12



# Assembly Instructions

If you have damaged or missing components,
email: **aftersales@gpmfurniture.co.uk**

## Step 13




## Step 14